



STOCKAR. FEEDER OF ROLLS FOR MACHINES THAT WORK CHANGING OR FEEDING THE ROLLS CONSTANTLY. THIS AVOIDS WASTING TIME IN THE PRODUCTION PROCESS.





STOCKAR has been specially designed to automatically feed the AUTEX extender model Lider Plus and for those companies that have to change rolls without finishing the one in machine, as well as those that before starting to extend are prepared all the parts that enter a mattress, so as not to have to go looking for them, or that due to their needs of extended hayt one operator for the machine and another preparing the parts. It has a platform to pick up the roll that is spreading, or to pick up the cardboard tube and load the next automatically in a few seconds.

It can also be attached to the Autex chargers models Cargo-80, 100, 300, 500 and Cartecno, so that they deposit them inside the cradle of their respective model of extending machine.

STOCKAR is composed of an iron chassis and a unique conveyor belt with all the useful width that by means of the start-up button we feed the parts one by one, in addition to a ramp, to collect the unfinished part or cardboard tube.

Operating through a control panel with push buttons at the beginning and end of the table.

On the back is to load the parts and on the front to feed the charger.

STOCKAR can be supplied in three roll capacities:

Stockar standard:

Capacity of 7 rolls of 25cm

Capacity of 5 rolls of 35cm

Capacity of 4 rolls of 50cm

Capacity of 3 rolls of 70cm

Stockar medium:

Capacity of 12 rolls of 25cm

Capacity of 8 rolls of 35cm

Capacity of 6 rolls of 50cm

Capacity of 5 rolls of 70cm



Stockar extra:

Capacity of 16 rolls of 25cm

Capacity of 11 rolls of 35cm

Capacity of 6 rolls of 70cm

On the back is to load the parts and on the front to feed the charger.





C/ Can Negoci, 18 - Pol.Ind. Can Negoci 08310 Argentona - Barcelona – Spain Telephone: +34 93 7589325 <u>ventas@autex-int.com</u> <u>www.autex-int.com</u>

